
rst_ps8_99M
Processor System Reset
axi_smc1
AXI SmartConnect
zynq_ultra_ps_e_0
Zynq UltraScale+ MPSoC
ps8_0_axi_periph
AXI Interconnect
axi_intc_0
AXI Interrupt Controller
dac_rst_128M
Processor System Reset
dac_dma_0
AXI Direct Memory Access
adc_rst_64M
Processor System Reset
axis_packet_controll_0
axis_packet_controller_v1_0_v1_0
adc_dma_0
AXI Direct Memory Access
axi_smc
AXI SmartConnect
xlconcat_0
Concat
usp_rfdc0
Zynq UltraScale+ RF Data Converter
adc1_clk
dac2_clk
vin1_01
sysref_in
vout20